

# distyNotruf<sup>pro</sup>

The lifesaver arm.

# disty



**A distress  
call button for  
your cordless  
telephone!**



## Users brief manual

Certified  
Product



Made in Germany

[www.disty.de](http://www.disty.de)



This Instruction shows how to use the device. Information about configuration on [www.disty.de](http://www.disty.de)

Modus	Leuchtdiode/Ton	
Put into charger	"beep" tone, red LED illuminates once	
Connected to charging cable	Red LED flashes during charging and turns off when charging is completed (flash rhythm: every second)	
Low battery	Red LED flashes once in every 30 seconds and "beep" tone	
Subscribed & registered	Green LED flashes once every 10 s	
Subscribed, out of range/ no base station	Red LED flashes every second	
DECT-connection	Green LED is switched on	
Alarm	Red LED flashes once every 0,5 s	
Incomming call	Green LED flashes one "beep"	
Range (Limit)	Red LED flashes fast. Warning tone.	

## Various ways to wear the tag

The **distyNotruf<sup>PRO</sup>** can be worn or fastened to your body in three different ways.



### Possibility 1: Fastening at the wrist.

The **distyNotruf<sup>PRO</sup>** comes ready to wear at the wrist. Place the device on your arm with the charging socket directed towards your body. Put the short end of the wrist band through the hole from the other part of the wrist band and pull tight. Press the pins of the fastener part firmly into the holes of the opposite part of the wrist band.

In case of dismounting press a small stick, like a paper clip, into the outside of the hole of the tag so that the spring bar can be removed.



### Possibility 2: Fastening with the belt clip.

Dismount the wrist band as described in Possibility 1. Remove the spring bars from the wrist band and mount one at the side of the charging socket.

Press the middle part of the belt clip with your finger tip so that the tongue appears at the other side and place it under the spring bar as illustrated.

Put the second spring bar into the opposite side of the belt clip. Bring the clip almost to its end position and place one side of the spring bar into the hole of the tag. Now push in the other side of the spring bar and press the belt clip firmly into its end position.





**Possibility 3:**  
**Fastening with the Lanyard.**

As a prerequisite mount the belt clip as described before. Squeeze in the Lanyard under the clip.

**Manufacturer's address:**

disty communications GmbH  
Holzkoppelweg 14 · D-24118 Kiel  
Phone: +49431-3645801  
Servicephone: +49431-3645822  
Fax: +49431-3645810

**[www.disty.de](http://www.disty.de)**